

# Cal. 5D22, 5D44

<b>INSTRUCTIONS</b>	<b>(P. 3)</b>
<b>BEDIENUNGSANLEITUNG</b>	<b>(S. 23)</b>
<b>INSTRUCTIONS</b>	<b>(P. 43)</b>
<b>ISTRUZIONI</b>	<b>(P. 63)</b>
<b>INSTRUCCIONES</b>	<b>(P. 83)</b>
<b>INSTRUÇÕES</b>	<b>(P. 103)</b>
<b>用法説明</b>	<b>(123 頁)</b>

You are now the proud owner of a SEIKO KINETIC® Cal. 5D22/5D44. For best results, please read the instructions in this booklet carefully before using your SEIKO KINETIC®. Please keep this manual handy for ready reference.

Sie sind jetzt stolzer Besitzer einer SEIKO KINETIC® Cal. 5D22/5D44. Lesen Sie diese Bedienungsanleitung vor der Verwendung Ihrer SEIKO KINETIC® aufmerksam durch, um die optimale Nutzung dieser Uhr zu gewährleisten. Heben Sie diese Bedienungsanleitung gut auf, um jederzeit wieder nachlesen zu können.

Vous voici l'heureux propriétaire d'une montre SEIKO KINETIC® Cal. 5D22/5D44. Pour en obtenir de bonnes performances, veuillez lire attentivement les explications de ce mode d'emploi avant d'utiliser votre montre SEIKO KINETIC®. Conservez ce mode d'emploi pour toute référence ultérieure.

Grazie di aver acquistato questo orologio SEIKO KINETIC® Cal. 5D22/5D44. Per ottenerne i migliori risultati leggere attentamente le istruzioni di questo libretto prima di passare all'uso dell'orologio stesso. Tenere poi il manuale a portata di mano, per ogni eventuale futura, ulteriore consultazione.

Usted es ahora un orgulloso propietario de un Reloj SEIKO KINETIC® Cal. 5D22/5D44. Para los mejores resultados, por favor lea las instrucciones de este librito cuidadosamente antes de utilizar su Reloj SEIKO KINETIC®. Le rogamos que guarde este conveniente manual para pronta referencia.

Você pode sentir-se orgulhoso de ter adquirido um SEIKO KINETIC® Cal. 5D22/5D44. Para obter dele os resultados máximos, solicitamos-lhe que, antes de usar o seu SEIKO KINETIC®, leia atentamente as instruções contidas neste opúsculo. E guarde este manual para referências futuras.

歡迎您購買精工 5D22/5D44 機型動力錶 (R)。為了更好地使用動力錶 (R)，請您在使用前仔細閱讀本說明書，並將其妥善保管，以備隨時用於參考。

# CONTENTS

	Page
FEATURES .....	4
DISPLAY AND BUTTON OPERATION .....	5
CROWN WITH DRIVING WHEEL.....	7
HOW TO CHARGE AND START THE WATCH.....	8
HOW TO READ THE DIRECT DRIVE INDICATOR .....	10
TIME/CALENDAR SETTING. ....	17
IMPROPER FUNCTION .....	19
AUTOMATIC HAND ALIGNMENT .....	20
POWER SOURCE (KINETIC E.S.U.) .....	21
SPECIFICATIONS .....	22

☆For the care of your watch, see "TO PRESERVE THE QUALITY OF YOUR WATCH" in the attached Worldwide Guarantee and Instruction Booklet.

## FEATURES

Unlike the conventional quartz watch powered by the button-type battery, the KINETIC is an analog quartz watch equipped with an Automatic Generating System, the unique technology developed by SEIKO, which generates electrical energy to power the watch by utilizing the movement of the arm or wrist, and stores it in the KINETIC ELECTRICITY STORAGE UNIT (KINETIC E.S.U.) The watch is equipped with a direct drive indicator that constantly displays how long the watch will keep operating. The direct drive indicator also dynamically displays the electric power generation status while charging the watch.



### CAUTION


- **The movement of your arm while the watch is worn generates electrical energy to power the watch. Even if the watch is worn on your arm, it will not be charged while your arm is not in motion.**
- **It is recommended that the watch be worn on your wrist daily for at least 10 hours.**
- **If you do not wear the watch for more than the continuous operating time that it displays, charge the watch as necessary so as not to stop operation of the watch until the next time you wear it. Refer to “How to charge and start the watch” for further details.**

❖ *THE KINETIC E.S.U. is an abbreviation for KINETIC ELECTRICITY STORAGE UNIT, which is the name of the power source employed in the KINETIC movements.*

## DISPLAY AND BUTTON OPERATION


### ● CAL. 5D44

Button (only used for special operations)



❖ The position of the date window and day hand may differ depending on the model.

## ● CAL. 5D22




❖ The position of the date window may differ depending on the model.


## CROWN WITH DRIVING WHEEL

- ◆ Some models may have a crown with a special structure as illustrated below. Refer to the following instructions when operating this type of crown, as it should be operated in a different way from that of ordinary ones.


Normal position



First click position




Second click position




To pull out the crown, pull out the **A portion** (crown).  
To turn the crown, turn the **B portion** (driving wheel).

## HOW TO CHARGE AND START THE WATCH



1. Turn the crown clockwise repeatedly to charge the watch.

- \* *The manual winding mechanism for generating the electric power functions when the crown is turned clockwise. The watch can also be charged when the crown is turned in a reciprocating motion.*
- \* *When the watch is completely stopped, the direct drive indicator hand points at scale marking 1 under the 0 position (standby position).*




2. After electric power generation by turning the crown continues for a certain period, the direct drive indicator hand moves to point at scale marking 0 and the second hand starts moving. Make sure to stop turning the crown to check it.

- \* *If the second hand does not move even though the crown is turned, turn the crown more quickly.*
- \* *If the watch has been left untouched for several years, the second hand starts moving in 2-second intervals after the crown is turned. This is not a malfunction. Charge the watch by turning the crown until the direct drive indicator hand moves from the standby position to the 0 position. It may take approximately 5 to 6 minutes.*



### 3. Continue to turn the crown to sufficiently charge the watch.


- \* *The direct drive indicator hand moves up and down to display the electric power generation status.*
- \* *When you stop turning the crown, the indicator hand displays the amount of power generated by the current manual winding for approximately 4 seconds, and then the hand returns to display the total amount of power reserve. Charge the watch until the indicator hand points at the second marking above "0" (approximately 6 hours of power reserve).*
- \* *This watch will keep on operating for approximately 1 month (30 days) if it is fully charged. However, it is not necessary to charge the watch fully, as it is charged automatically while it is worn on your wrist.*
- \* *Refer to "How to read the direct drive indicator" for further details.*



## HOW TO READ THE DIRECT DRIVE INDICATOR

The direct drive indicator can be used to check the following:

- (1) Power reserve amount (continuous operating time)
- (2) Real-time power generation status and newly generated amount of power while charging the watch



## ■ POWER RESERVE INDICATOR

- The watch checks power reserved in the KINETIC E.S.U and displays how long the watch will keep operating in 18 steps (0 - M scale marking).
- The continuous operating time until approximately one month (30 days) can be displayed.

- \* *The power reserve indicator provides an approximate time that the watch keeps operating without needing to be charged.*
- \* *If the direct drive indicator hand moves to the 0 position, the watch will stop operating within 3 hours. When the watch stops, the indicator hand moves to the standby position to show that the watch stops operating due to a power shortage.*
- \* *If the crown is turned after the watch is fully charged, the indicator points at the "M+1" position.*

## ■ REAL-TIME POWER INDICATOR

- While turning the crown to charge the watch, the watch checks a newly generated amount of power and displays it in 19 steps (0 - "M+1" scale marking).
- A maximum 6 hours of generated power can be displayed.

- \* *The real-time power indicator provides an approximate amount of power generated through current power generation.*
- \* *After power generation by turning the crown is completed, the indicator hand will display the amount of newly generated power for approximately 4 seconds, and then the indicator hand will move to display the total amount of power reserve.*

## ■ SCALE TABLE OF POWER RESERVE AMOUNT AND GENERATED POWER AMOUNT

Scale marking	Standby position	0	1	2	3	4	5	6	7	8	9	10	11
Indication on dial		0				12 (12 h)				D (Day)			
Power reserve amount	The watch stops operating.	0	3 H	6 H	9 H	12 H	15 H	18 H	21 H	1 D	2 D	3 D	4 D
Amount of generated power		0	20 Min.	40 Min.	1 H	1 H 20 Min.	1 H 40 Min.	2 H	2 H 20 Min.	2 H 40 Min.	3 H	3 H 20 Min.	3 H 40 Min.

Scale marking	12	13	14	15	16	17	18
Indication on dial	0		W (Week)		12	M (Month)	
Power reserve amount	5 D	6 D	1 W	2 W	3 W	30 D	
Amount of generated power	4 H	4 H 20 Min.	4 H 40 Min.	5 H	5 H 20 Min.	5 H 40 Min.	6 H

*H : Hour*

*D : Day*

*W : Week*

\* *The minimum amount of power reserve and generated power is described in the table.*

Ex.) How to read the scale table of power reserve and generated power.

Scale marking	Power reserve
3	Not shorter than 9 hours and not longer than 12 hours
9	Not shorter than 2 days and not longer than 3 days
17	30 days

Scale marking	Generated power
3	1 hour or more
9	3 hour or more
18	6 hour or more

## ■ HOW TO READ THE DIRECT DRIVE INDICATOR WHILE CHARGING THE WATCH

1. Turn the crown clockwise. After approximately 1 second, the direct drive indicator hand starts moving.
2. Continue to turn the crown. The indicator hand moves upward and downward according to the power generation status. When further continuing to turn the crown, the point where the indicator hand starts moving goes up as the amount of generated power increases. If you temporarily stop turning the crown, the indicator hand goes down to display the accumulated power generated by the current power generation.
3. Stop turning the crown. The direct drive indicator hand returns to display the total amount of power reserve after approximately 4 seconds.

\* *After the crown is turned repeatedly, the indicator hand will stop at the maximum scale value ("M+1" position).*

*If the crown is turned after the indicator hand stops at the "M+1" position, the watch continues to accumulate power reserve, but stops displaying the power generation status. If you want to display the power generation status, stop turning the crown, and after the indicator hand returns to display the power reserve, start turning the crown again.*

\* *If turning the crown more quickly and in long strokes so that the indicator hand makes large movement, the generated power increases efficiently.*


\* *Depending on intervals between turning the crown, the indicator hand may not move. This is not a malfunction.*

\* *The watch is equipped with a system to prevent overcharge. Even if the crown is turned when the indicator hand points at the maximum scale value of power reserve, no malfunction*

will result.


- \* *The watch can be charged if it is swung from side to side, however, it may take time until it displays the power generation status.*
- \* *Even if the watch is worn on the wrist after it is charged fully (power reserve of 30 days), and then it is left untouched, the watch will not operate for more than 30 days after it is worn again.*
- \* *When you take off the watch and leave it untouched, look at the indicator to check if the watch continues to operate until you wear the watch the next time, and turn the crown to charge the watch as necessary (make sure to store extra power so as not to stop operation of the watch).*

## <Display and movement flow of the direct drive indicator hand while charging the watch>





## TIME/CALENDAR SETTING



1. Pull out the crown to second click when the second hand is at the 12 o'clock position.

2. Turn the crown to set the time.


\* When setting the hour hand, check that AM/PM is correctly set. The watch is designed so that the calendar changes once in 24 hours.

Turn the hand past the 12 o'clock marker to determine whether the watch is set for the A.M. or P.M. period. If the calendar changes, the time is set for the A.M. period. If the calendar does not change, the time is set for the P.M. period.

\* When setting the minute hand, advance it 4 to 5 minutes ahead of the desired time and then turn it back to the exact minute.

3. Push the crown back in to the normal position in accordance with a time signal.

## ■ HOW TO SET THE DATE AND DAY (DAY SETTING ONLY FOR 5D44)



1. Pull out the crown to first click.
2. Turn the crown counterclockwise until the current date appears.
3. Turn the crown clockwise to set the day hand to point at the correct day of the week.

\* Do not set the date and day of the week between 9:00 p.m. and 3:00 a.m. Other wise, it may not change properly.


\* It is necessary to adjust the date and day of the week on the first day after a 30-day month and February.

4. Push the crown back in to the normal position.

## IMPROPER FUNCTION

When the watch stops operating even though it displays the remainder of the power reserve, follow the instructions below to reset the built-in IC.

### ■ HOW TO RESET THE BUILT-IN IC



1. Pull out the crown to the second click.
2. Press the button for 2 seconds or more using a sharp-pointed tool (e.g. ball point pen).
3. Push the crown back into the normal position.

\* The indicator hand will point at the 0 position, and the watch resumes its normal operation.

- \* *If the indicator hand points at under the 0 position, sufficiently charge the watch. Refer to "How to charge and start the watch".*
  - \* *By conducting this operation, the indicator hand moves to the 0 position even though it displayed that there was remaining power reserve; however, this is not a malfunction.*
  - \* *If the watch does not resume normal operation even after resetting the built-in IC, consult the retailer from whom the watch was purchased.*
4. Turn the crown to charge the watch at least until the indicator hand points at the second marking above "0"(approximately 6 hours of power reserve). And then set the time, date, and day of the week.

## **AUTOMATIC HAND ALIGNMENT**

The position of the indicator hand may move out of alignment in rare cases. The watch automatically corrects the position of the indicator hand once every 24 hours. While correcting the hand position, the indicator hand moves abnormally, however, this is not a malfunction. After automatic hand alignment is performed, the indicator hand will return to display power reserve amount.

### **<About the movement of the indicator hand during automatic hand alignment>**

When automatic hand alignment starts, the indicator hand moves to the area under the 0 position and vibrates, and then points at the 0 position. After automatic hand alignment is completed, the indicator hand returns to display power reserve amount.

## POWER SOURCE (KINETIC E.S.U.)

This watch requires no periodic battery replacement as it is powered by the exclusive secondary battery, which is completely different from conventional batteries for watches.

This exclusive secondary battery is an environmentally friendly, clean energy storage device.



### CAUTION

**Never install a silver oxide battery for conventional watches in place of the KINETIC E.S.U. , which can generate heat that can cause bursting or ignition.**

## SPECIFICATIONS

- |    |                                       |   |
|----|---------------------------------------|---|
| 1  | Frequency of crystal oscillator ..... | 32,768 Hz (Hz = Hertz ... Cycles per second)  |
| 2  | Loss/gain (monthly rate) .....        | Less than 15 seconds (worn on the wrist at normal temperature range 5° C ~ 35° C)   |
| 3  | Operational temperature range .....   | -10° C ~ +60° C   |
| 4  | Driving system .....                  | Step motor: 2 pieces  |
| 5  | Display system .....                  | Hour, minute, second, date, and day of the week (day display only for 5D44)<br>Power reserve display, power generation status display, and generated power amount display |
| 6  | KINETIC electricity storage unit..... | Button type, 1 piece  |
| 7  | Duration of charge .....              | Approximately 1 month (if the watch is fully charged)   |
| 8  | Additional functions .....            | Overcharge prevention function  |
| 9  | IC (Integrated Circuit) .....         | C-MOS-IC, 1 piece   |
| 10 | Generating system .....               | Miniature AC generator  |
- \* The specifications are subject to change without prior notice for product improvements.